



Dura-Post™ Surface Mount Epoxy Kit Installation Instructions

For Installation on Asphalt or Concrete

Caution: Always wear protective clothing and personal protective equipment (PPE) such as eye protection, work gloves, and steel toe work boots while doing the following work.

1. Check that you have all parts necessary for the installation. You should have post(s), surface mount base(s) and epoxy kit.



2. Locate and mark durapost location(s). A clean, dry surface is required.
3. Mix epoxy kit (part no. SHEPX-13--KI) 5 oz Part "A" and 5 oz Part "B" of 1101 concrete epoxy.

Note: The epoxy is easiest to work with if it is warmed to at least room temperature.



3. Apply epoxy evenly to bottom of base including the middle.



4. Press base down firmly on surface until a bead of epoxy appears around edge. Be sure that the arrow is facing traffic.

ARROW



5. Allow to cure approximately one hour (when temperature is above 80 deg.) before installing post (allow extra time for cold weather).
6. Insert post and drive locking pins in place with hammer. To remove post, use drift pin to remove locking pins, then lift post from base.

