



## **GUARDRAIL DELINEATOR INSTALLATION INSTRUCTIONS**

The following instructions are meant to familiarize workers with the proper installation procedures of SAFE-HIT Guardrail Delineator using self tapping screws or nails.

Worker safety and the use and proper handling of tools and equipment are paramount and should be followed at all times. The use of personal protection devices such as eye, hearing protection and gloves is recommended at all times.

The following tools are recommended for proper Guardrail Delineator installation:

- Steel Post Screw Attachment
- 5/16" Standard Depth Socket
- Cordless Drill with Socket Adapter
- Wood Post Nail Attachment
- 16oz. (min.) Hammer

### INSTALLATION PROCEDURE FOR STEEL POSTS USING SCREWS

1. Locate the steel posts for attachment of the guardrail delineators
2. Place delineator with self tapping screws pre-installed in position at the desired post or rail.
3. Plumb the delineator so it is vertical and the bottom of the SAFE-HIT label is even with the top of the post or rail.
4. Drill the self tapping screw with the socket drill into the post or rail until the delineator is flattened by the screw's sealing washer.
5. Repeat for the drilling of the second pre-installed screw to complete the installation.

### INSTALLATION PROCEDURE FOR WOOD POSTS USING NAILS

1. Locate the wood posts or rails for attachment of the guardrail delineators.
2. Place delineator with self sealing nails pre-installed in position at the post.
3. Plumb the delineator so it is vertical and the bottom of the SAFE-HIT label is even with the top of the post.
4. Drive the nails with the hammer into the post until the delineator is flattened by the nail's sealing washer.

If you have any questions please contact our Customer Service Department at 1-800-537-8958.



**SAFE-HIT**, 35 EAST WACKER DRIVE, SUITE 1100, CHICAGO IL 60601  
PH: (800) 537-8958 FX: (800) 770-6755