

KonaPost™ Installation Instructions

For Installation in Asphalt or Concrete

Caution: Always wear protective clothing and personal protective equipment (PPE) such as eye protection, work gloves, and steel toe work boots while doing the following work.

1. Check that you have all parts necessary for the installation. You should have a KonaPost™, Base and epoxy kit.



2. Locate and drill 1 3/4" diameter x 8 1/4" deep hole per site plan.



3. Blow out hole with compressed air to remove all debris. A clean, dry surface is required inside hole and within a 4" diameter outside the hole.
4. Mix epoxy kit (part no. SHEPX-13--KI) 5 oz Part "A" and 5 oz Part "B" of 1101 concrete epoxy.

Note: The epoxy is easiest to work with if it is warmed to at least room temperature.



5. Apply generous amount to outside diameter and the underside of top plate of the KonaPost™ anchor (part no. 2744000-0000).



6. Insert the KonaPost™ anchor into the hole and press down firmly on the top plate until a bead of epoxy appears around the edge.



7. Allow epoxy to cure approximately one hour before installing post (part no. SHLG19GPR--_X).

