

# RubberTough<sup>®</sup> 360 Surface Mount

## INSTALLATION INSTRUCTIONS

This procedure describes the process to install the RubberTough 360 surface mount base permanently to asphalt or concrete.

### Tools Required & Materials:

- Tape Measure
- Marking Chalk or Crayon
- Roto Hammer
- 13/16" Socket
- 1/2" Carbide Tipped Masonry Drill Bit
- Electric Impact Wrench or Socket Wrench
- 2701030-0100 5/8" x 4" Self Threading Anchor Screws

### Procedure:

**Step 1:** Mark the location of the two holes, spaced 6-1/2" apart

**Step 2:** Use a roto hammer to drill two 1/2" holes to a depth of 5".

**Step 3:** Set the RubberTough 360 post base in position and

**Step 4:** Install the 5/8" x 4" self-threading anchor screws with an electric impact wrench or a by hand with a socket wrench. Tighten until fully seated.



**Step 1:** Mark hole locations  
6-1/2" apart



**Step 2:** Drill holes



**Step 3:** Install anchor screws

### Notes:

This mounting system is meant for permanent applications, meaning the screws are not designed to be removed and re-installed in the same holes. If removal and re-installation is necessary, either drill a new set of holes no closer than 3" to the existing holes or re-install the screws using Energy Absorption System's MP3 adhesive product. Note, if the later option is chosen, then the screws will not be able to be removed in the future.

**Important!** Mount the base with a minimum space of 4" from the edge of the road.



SAFE-HIT, 35 EAST WACKER DRIVE, SUITE 1100, CHICAGO IL 60601  
PH: (800) 537-8958 FX: (800) 770-6755