

RubberTough® 360 Soil Anchor

Installation Instructions

This procedure describes the process to install the RubberTough 360 soil anchor.

Tools Required:

- Motorized Hammer with Safe-Hit Shank SHTOL-XX--HT or Safe-Hit Hand Driver p/n SHTOL-30-6-X
- ¾" Socket Wrench or Box End Wrench

Procedure:

Step 1: Position the anchor so that the top plate long edge is parallel to the direction of traffic. Make sure the ½" bolts are securely in place on the anchor plate.

- Push the anchor in by hand about 1" to 2".
- Stand on the side of the anchor with the point of the "V" and set the driver tool in place, then tilt the anchor toward yourself at about a 10 degree angle.
- Step 4: Drive the anchor into the ground until it contacts the surface. As you drive the anchor it will begin to rotate to a vertical orientation.

Step 2: Remove the ½" bolts from the anchor plate.

Step 3: Place the RubberTough 360 post on the anchor top plate and install the two ½" bolts with flat washers and lock washers. Tighten snugly.



Step 1: Begin with the anchor set at an angle.



Step 2: Remove the ½" bolts.



Step 3: Install the post.